EasyPad Trouble-Shooting Chart

Use this trouble-shooting chart when one or more red hearts are displayed while doing a recall or final.

```
                    ┌──────────┐
                    │  Start   │
                    └────┬─────┘
                         │
              ◇ Is the problem ◇ ──yes──▶ ( Wi-Fi channel is too busy.
              ◇ intermittent?  ◇           Change channel )
                         │ no
                         ▼
         ◇ How many pads are showing ◇ ──one pad──▶ ◇ Is the pad's screen on? ◇ ──no──▶ ( Replace the pad )
         ◇ red hearts?              ◇                         │ yes
                    │ all pads                                ▼
                    ▼                            ◇ Is pad connected to Easycomp? ◇ ──no──▶ ( Connect the pad )
         ◇ Does router have power? ◇ ──no──▶ ( Power the router )      │ yes
                    │ yes                                      ▼
                    ▼                              [ Disconnect and reconnect pad ]
         ◇ Is ethernet cable connected? ◇ ──no──▶ ( Connect the cable )    │
                    │ yes                                      ▼
                    ▼                                ◇ Is problem fixed? ◇ ──no──▶ ( Replace the pad )
            ( Change the router )                             │ yes
                                                              ▼
                                                        ┌──────────┐
                                                        │   End    │
                                                        └──────────┘
```